



Drill the holes for the plugs - Screw the 1st deck board - Insert the plugs



Insert the fastener - Screw the fastener at approximately a 45° angle through the deck board and down into joist



Install the next deck board until it abuts the integrated spacer



Repeat steps 2 and 3 until the last deck board is installed. Repeat step 1 to attach the last board

